

NOTES:

- 1. INSTALL PER MANUFACTURER'S RECOMMENDATIONS.
- 2. SLOPE SURFACE SHALL BE MADE SMOOTH PRIOR TO PLACEMENT OF BLANKET.
- DO NOT STRETCH BLANKETS TIGHT. ROLL FROM THE BOTTOM OF THE SLOPE TO THE TOP, ALLOWING BLANKET TO BE IN DIRECT CONTACT WITH THE EXPOSED SOIL.



NO SCALE

TITLE

EROSION CONTROL BLANKETS AND NETS

NO. <u>EC-15</u>

REV. DATE ______10/2000